

Art.S001-S002 SOLAR MODULE WITH DELIVERY AND RETURN CONNECTIONS




Technical Information sheet 0001/07/Rev01 ENG

FUNCTION

Series S001 and S002 circulation units are applied to the primary circuit of solar systems and oversee management of the solar panel - storage tank fluid thermodynamic cycle for subsequent supply to utilities via hydraulic distribution circuits.

They consist essentially of a circulator with appropriate performance (rate of flow/head) and regulation and control devices governing the operating circuit.

Art.S001



Art.S002



TECHNICAL FEATURES

Fluid used	Water, glycol solutions (glycol 25%÷50% max)
Calibration of safety valve	6 bar
Connection	3/4" gas
Permitted temperature range	-10 °C / +130°C
Max. ambient temperature	+40°C
Max. operative pressure	10 bar
Min. pressure on intake	
opening with temperatures of:	+50 °C : 0,05 bar
	+95 °C : 0.3 bar
	+110 °C : 1 bar


Body	brass EN 12165 CW617N
Thermometer	steel/alluminium
Seals	PTFE
Sealing elements	EPDM-Perox
Flat seals	Betaflex
Insulation shell	PPE, Conducibility $\lambda(\Delta T)$: 0.041 (W/mK)
Manometer scale	0÷6 bar
Thermometer scale	0÷160 °C
Connections	3/4" F
Hose fitting, for connection with expansion tank	3/4" M

Safety valve temperature range	-30÷160°C
Calibration of safety valve	6 bar
Min. pressure for opening on/off and check valve connection	Δp : 2Kpa (200mm c.a.)


Model Wilo Solar ST20/6 pump

Centre-to-centre distance: 130 mm between connections
Electrical power supply: 230V - 50Hz
Operative temperature: -10°C÷110°C approx.
Max. temperature: 140°C for max 2 hours
Max. operating pressure: 10 bar
Protection level: IP 44
Connection to the electric network with Molex-type adaptor

Hydraulic features of Wilo ST20/6 pumps



-30÷160°C
6 bar
 Δp : 2Kpa (200mm c.a.) Filling/emptying connections with hose Ø13 mm




COMPONENTS

TAB N.1

1. Safety valve for solar energy systems Art.S121 G1/2" – 3/4"
2. Instrument holder connection with manometer
3. Taps for filling, emptying and washing the system
4. On/off valve with built-in thermometer and return connection with Anti-gravity non return valve
5. Wilo Solar ST20/6 circulation pump
6. Flow controller with on/off valve, return connection (scale range between 1+13 l/min).
7. On/off valve with built-in thermometer and delivery connection
8. Air bleeding device
9. Preformed insulating base
10. Hose connection
11. Preformed insulating cover
12. Inspection compartment insert
13. Molex connector
14. Cable duct groove

DIMENSIONS



TAB N.2

Code	A	B	C	D	E	F	G	H	I	L	Weight (Kg)
S001	G 3/4" F	100	130	310	478	440	260	50	60	166.5	7.0
S002	G 3/4" F	/	130	264	478	440	235	29	60	166.5	5.0

TECHNICAL SPECIFICATIONS

Modules S001 and S002 receive a signal from the external controller (differential temperature controller), which has at least two temperature sensors (one is positioned on the panel outlet pipe and the other is an immersion sensor in the boiler), constantly reading the temperature difference and keeping it within the established range, which normally varies between 5 and 8 °C. If the Δt between the panel and the boiler is found to be over the established set point, the controller starts up the pump on the module to provide the lacking thermal load. If, on the other hand, the Δt is narrower than the one set, the internal pump will be disabled. For further clarification about the electronic controller functioning, please consult the technical documentation 004/08 about art. S301 and S302.

FILLING THE SYSTEM

1. Open the on/off valve connected with the air bleed valve A (Fig.1), located at the highest point of the system.
2. Open the on/off and check valves, turning the ball valves with the handle with the thermometer on it (4, 7 in Tab.1).
3. Fill the system with a pump, using the tap at the lowest part of the system (3 in Tab.1), until air stops coming out of the air bleed A (Fig.1).
4. Close the on/off valve on the air bleed valve (7 in Tab.1).
5. Close the tap (3 in Tab.1).




Fig.1

WASHING THE SYSTEM

1. Close the flow control ball valve (6 in Tab.1).
2. Let fluid flow through the solar panels and the heat exchange circuit using an external washing pump linked via a rubber hose to the safety unit filling/emptying tap (1, 2, 3 in Tab.1), until fluid flows out of the flow controller filling/emptying tap (3 in Tab.1).
3. Briefly open the ball valve in the flow controller (6 in Tab.1) to expel all the air from the system.
4. Leave the external pump running in the system for a few minutes to make sure that it is thoroughly washed, following the instructions provided with the external washing pump.

START-UP

1. Close the filling/emptying tap on the flow controller (6 in Tab.1) and increase the system's pressure up to the maximum permitted value. Close the tap when this value is reached.
2. Open the valve on the on/off assembly (4, 7 in Tab.1) and operate the pump (5 in Tab.1).
3. Leave it to circulate for a certain amount of time, and then check the hydraulic seals in the system.
4. Open the air bleed valves A (Fig.1) again, removing air from the system again by turning on the circulation pump briefly.
5. Restore the desired air pressure.
6. The rate of flow of the system may be modified using the flow controller (6 in Tab.1), working the ball valve above the graduated scale (refer to flow meter description). In order to do this the pump must be set to maximum power. Follow the solar panel manufacturer's instructions to adjust or limit the rate of flow.
7. After a few hours of operation, remove air from the solar energy system again at the highest point in the system A (Fig.1) and in the air separator (8 in Tab.1). When you have finished bleeding air, check the pressure in the system and restore the desired operating pressure if necessary.

EMPTYING THE SYSTEM

The system must be emptied if it has been filled with water only and will be exposed to a risk of freezing.

1. Open the on/off and check valves by turning the thermometer holder to 45° (4, 7 in Tab.1).
2. Open the air bleed devices at the highest point A (Fig.1).
3. Open the emptying tap at the lowest point in the system (3 in Tab.1).

INSTALLATION AND WALL MOUNTING

Modules S001 and S002 are anchored using two supporting brackets C (Fig.3) situated at the back of the shell (9 in Tab.1), screwed in with 2 screws (M8x35mm) with washers (Fig.2) stored in a bag inside the box which must then be screwed into the corresponding screw anchors after inserting them in the wall (Fig.3).

Proceed as follows to install:

1. Lay the pipes for the entire system, leaving the amount of space shown in Table N.2
2. Determine the position of the screw anchors and insert them in the wall
3. Anchor the solar unit to the wall using the screws provided and connect it with the pipes
4. Wire it up electrically
5. Check that all unions are tight





Fig.3


FLOW METER

The flow meter (6 in Tab.1) is an instrument for measuring the rate of flow of fluid circulating in the system. The flow meter has a rate of flow limiter which may be adjusted manually with a screwdriver (Fig.4). A rate of flow indicator present inside the measurement device and a graduated scale on the glass permit real time display of the rate of flow in the circuit (Fig.5). The scale's range is 1÷13 l/min. The only possible position for assembly is vertical (Fig.4).




CHECK VALVE AND ON/OFF VALVE

The assembly has an on/off valve with thermometers incorporated in the adjustment flywheels (4, 7 in Fig.6). The valves permit interception of delivery (7 in Tab.1) and return (4 in Tab.1) flow to permit replacement of the pump (while shut down) even when the system is full. To permit fluid to flow in both directions, it is necessary to turn the flywheels on the ball valves 45° (Fig.7). During normal operation the valve should be turned to the fully open position (Fig.8).



AIR BLEED DISTRIBUTOR (air separation device)



Solar module S001 has an air bleed distributor (8 in Tab.1) positioned on the delivery line. Gases are separated from the head conveying fluid and accumulate in the upper part of the deaerator.

During start-up, accumulated gases must be evacuated periodically during the day using the manual air bleed valve, with a screwdriver appropriate to the size of the bleed valve.

After this, depending on the amount of air in the system, the operation may be repeated either once a week or once a month.

Lastly, use the deaerator to bleed the system once every 6 months to keep the solar installation running efficiently.



Danger of burning !

When bleeding the system, if fluid pressure and temperature are high enough, slackening the screw could produce a jet of superheated liquid or steam.

Proceed as follows to avoid accidents:

- Carefully push and turn the rod inwards using an appropriate screwdriver.
- Protect components and electrical connections from water.
- Start up the pump again.

SAFETY

Safety warnings



Read assembly and operating instructions carefully before starting up the system in order to prevent accidents and damage to the system caused by improper use. Remember that your rights under the warranty will be forfeited if you make any changes to the system or tamper with it during assembly and construction without authorisation. In addition, you must follow the requirements of the regulations listed below:

DIN 4751
Water heating systems

DIN 4757
Solar heating systems

DIN 18380
Heating systems and hot water heating systems

DIN 18382
Electrical systems and pipes in buildings

DIN 12975
Thermal solar systems and components

OPERATING CONDITIONS

The limits on operating values specified must not be exceeded under any circumstances. Safe operation is guaranteed if you comply with the general conditions and limits on operating valves described in this information sheet.

SAFETY STANDARDS FOR ASSEMBLY AND INSPECTION

Assembly and inspection operations must always be performed by qualified, authorised personnel familiar with the instructions contained herein. Make sure the system is shut down before performing any work on it.

ELECTRICAL CONNECTIONS

Electrical connections must be made by qualified personnel. Connecting cables must be positioned in the cavity provided for the purpose in the insulating shell (14 in Tab.1) so as to avoid contact with the body of the pump motor and with pipes. Check that the power supply voltage is as specified on the plate before turning on the pump. All connections must be made as required by law.

MAINTENANCE

Maintenance work must always be performed by qualified, authorised personnel familiar with the instructions contained herein. Make sure the system is shut down before performing any work on it. When replacing the pump, turn the on/off valve, return connection (4 in Tab.1) and flow control valve (6 in Tab.1) to the off position.



Warning! Depending on operating conditions in the pump and the system, the surface temperature could be very high. Touching the pump directly comports a risk of burning!

DECLARATION OF CONFORMITY (CE)

Wilo Solar ST20/6 pumps conform to the following harmonisation directives:

EEC Machinery Directive

89/392/CEE, 91/368/CEE, 93/44/CEE, 93/68/CEE.


Electromagnetic compatibility

89/336/CEE, 92/31/CEE, 93/68/CEE

General harmonised standards

EN 809, EN50081-1, en 50 081-2, EN 50 082-1,
EN 50 082-2.


Art.S002



Seat with plane gasket.
Lock the nuts before to fill the system
In let pressure < 3 bar



Art.S001



Seat with plane gasket.
Lock the nuts before to fill the system
In let pressure < 3 bar

